
Kits de joint

312561D
FRA

Pour le remplacement sur la pompe doseuse des ensembles de joint de piston ou de cylindre utilisés sur les doseurs hydrauliques.

Importantes consignes de sécurité
Se reporter au manuel réf. 312068 pour une description complète de toutes les mises en garde et consignes d'utilisation. Prendre connaissance de toutes les mises en garde et consignes d'utilisation décrites dans le présent manuel ainsi que dans le manuel réf. 312068. Garder les deux manuels d'utilisation.

FIG. 1 : Kits de joint de piston



Kit 261756





FIG. 2 : Kits de joint de cylindre



HO03

Les pièces cochées (✓) dans les tableaux suivants sont comprises dans les kits.



Avant de commencer, exécuter la procédure de décompression décrite dans le manuel réf. 312068.

Kits de joint de piston

Voir FIG. 1 pour les emplacements du joint de piston.

Pompe	Taille de la pompe	Kit	A (Joint de piston)	B (Douille)	C (Boulon)	D (Tige de piston)	E (Bouchon du piston)
24F291	28	261756	✔	✔		16F202	16F204
247371	30	261851	✔	✔	✔	261882	261889
247372	40	261850	✔	✔	✔	261881	261886
247373	48	261849	✔	✔	✔	261880	261886
247374	60	261848	✔	✔	✔	261879	261886
247375	80	261847	✔	✔	✔	261878	261883
247577	88	247578	✔	✔	✔	247584	261883
247376	96	261846	✔	✔	✔	261877	261883
247377	120	261845	✔	✔	✔	261876	261883
247576	140	247579	✔	✔	✔	247585	261883

Kits de joint de cylindre

Voir FIG. 2 pour les emplacements du joint de cylindre.

Pompe	Taille de la pompe doseuse	Kit	F (Joint de cylindre)	G (Palier)	H (Joint)	J (Bride de sortie)	K (Bride de retenue)	L (Bague d'adaptation)
24F291	28	261858	✔	✔	✔	261902	261875	261874
247371	30	261858	✔	✔	✔	261902	261875	261874
247372	40	261857	✔	✔	✔	261902	261875	261873
247373	48	261856	✔	✔	✔	261902	261875	261872
247374	60	261855	✔	✔	✔	261902	261875	261871
247375	80	261854	✔	✔	✔	261901	261875	261870
247577	88	247580	✔	✔	✔	261901	261875	247586
247376	96	261853	✔	✔	✔	261901	261875	261869
247377	120	261852	✔	✔	✔	261901	261875	261868
247576	140	247581	✔	✔	✔	261901	261875	247587

All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.

Original instructions. This manual contains French. MM 312071

WWW.DIAMONDLINERS.COM
Mailing Address
9507 Santa Fe Springs Road
Santa Fe Springs, CA 90670
Phone
(562) 781-1045 or (800) 543-1212
Fax
(562) 781-1045
Email
info@diamondliners.com